

<b>Zuordnung Regler</b>			
<b>Typ</b>	<b>Drehzahlsteller 5-stufig ohne Motor- vollschutz</b>	<b>Drehzahlsteller 5-stufig mit Motor- vollschutz</b>	<b>Motorvoll- schutzgerät</b>
GBW 250/4	TSW 1,5	–	–
GBW 315/4	TSW 1,5	–	–
GBW 355/4	TSW 1,5	MWS 1,5	MW <sup>1)</sup>
GBD 355/4/4	TSD 0,8	RDS 1	M4 <sup>2)</sup>
GBW 355/4 T120	TSW 3,0	MWS 3	MW <sup>1)</sup>
GBD 355/4/4 T120	TSD 0,8	RDS 1	M4 <sup>2)</sup>
GBW 400/4	TSW 3,0	MWS 3	MW <sup>1)</sup>
GBD 400/4/4	TSD 1,5	RDS 1	M4 <sup>2)</sup>
GBW 400/4 T120	TSW 3,0	MWS 3	MW <sup>1)</sup>
GBD 400/4/4 T120	TSD 1,5	RDS 2	M4 <sup>2)</sup>
GBW 450/4	TSW 5,0	MWS 5	MW <sup>1)</sup>
GBD 450/4/4	TSD 1,5	RDS 2	M4 <sup>2)</sup>
GBW 450/4 T120	TSW 7,5	MWS 7,5	MW <sup>1)</sup>
GBD 450/4/4 T120	TSD 3,0	RDS 2	M4 <sup>2)</sup>
GBW 500/6	TSW 3,0	MWS 3	MW <sup>1)</sup>
GBW 500/4	–	MWS 10	–
GBD 500/4/4	TSD 5,5	RDS 7	M4 <sup>2)</sup>
GBW 500/4 T120	–	MWS 10	MW <sup>1)</sup>
GBD 500/4/4 T120	TSD 3,0	RDS 4	M4 <sup>2)</sup>
GBD 560/6/6	TSD 3,0	RDS 4	M4 <sup>2)</sup>
GBD 560/4/4	TSD 7,0	RDS 7	M4 <sup>2)</sup>
GBD 560/4/4 T120	TSD 7,0	RDS 7	M4 <sup>2)</sup>
GBD 630/6/6	TSD 5,5	RDS 4	M4 <sup>2)</sup>
GBD 630/4/4	TSD 11,0	RDS 11	M4 <sup>2)</sup>
GBD 630/4 T120	–	FUG 12*	–
GBD 710/6/6	TSD 7,0	RDS 7	M4 <sup>3)</sup>